

Tuttnauer Water Distiller - 500/800 Models

TuttnauerTM
Your Sterilization & Infection Control Partners



Water Purifier with Electronic Monitor. Reduces up to 99% of most substances found in tap water

- No tools, no fittings, no soldering, no installation - No hassle.
- Eliminates the inconvenience and expense of buying bottled water. The Water Purifier lets you bottle your own water at a fraction of the cost
- With the Water Purifier you will produce up to 23 Liters of pure water per day
- Eliminates Cysts, Bacteria and Viruses
- Reduces 99% of Total Dissolved Solids
- Electronic Clock/Timer/Monitor (optional)
- Attractive 3.8 Liter Serving Carafe
- 800 Watts of Power. Plugs into any standard outlet
- Increases the life of water using appliances preventing mineral build-up, reduces Lead, Arsenic, Nitrates and Sodium



Tuttnauer Water Distiller - 500/800 Models

Here's how easy it is to enjoy the benefits of pure, crystal clear, water anytime.

Simply fill the main chamber with water from your tap. The water is then heated to 100°C; killing bacteria, eliminating Cryptosporidium, reducing lead, nitrates and other Total Dissolved Solids (TDS). The heated water is then converted to steam, which rises, leaving residual chemicals and other impurities behind. Lastly, the water is cooled and dispensed into the collection/serving carafe.

Pure steam is cooled in stainless steel condensing coils

The LCD monitor shows the time, provides automatic start and/or delay feature, indicates filter changing times and auto shut-off

"Stop-and-Serve" anti-drip valve lets you neatly and conveniently dispense pure water anytime

Convenient LCD readout
Multi-function clock/timer/monitor lets you know the status of the water you're purifying, provides automatic start-up while you are away, tells you when to change the filter and displays the time.



Purifying chamber heats water to 100°C, killing microbiological contaminants and cysts



* Optional

Removable boiling chamber is filled with four quarts of water

Purified water is collected in serving carafe ready for immediate use

Model qualifications	Model 500	Model 800
Daily production	15 Liter	23 Liter
Carafe Volume	2.8 Liter	3.8 Liter
Electrical supply	220-240 V	220-240 V
Cycle time	5 hours	4 hours
LCD readout	-	Yes

Pre & Post Vacuum

Automatic autoclaves

Manual autoclaves



Tuttnauer Tabletop Autoclaves

Tuttnauer Europe b.v.

Hoeksteen 11, 4815 PR, P.O.B. 7191, 4800 GD, Breda, The Netherlands

Tel: +31 (0) 765423510, Fax: +31 (0) 765423540, E-mail: info@tuttnauer.nl, www.tuttnauer.com

Tuttnauer™
Your Sterilization & Infection Control Partners